

# KWIK-CORE™ MATERIAL



## Eliminates the Need for Extra Shell Drying Time on Complicated Parts

Comprised of Kwik-Core™ powder and Kwik-Core™ binder, Kwik-Core material is designed for hand packing cores and is used primarily by ferrous casters. Due to its low exothermic reaction, Kwik-Core material can be poured directly into the cavity of the wax and can be applied against most wax patterns. Kwik-Core material is pourable for

easy application. It eliminates the need for extra shell drying time on complicated parts and is an ideal alternative to shelling narrow slots and passageways.

## Application Recommendations

Binder/Powder Ratio*	32/100 by weight (or 29 ml of binder per 100 g of powder)
Pouring Time	12-15 minutes
Setting Time	50-60 minutes
2-hour Green Strength	120 psi
1600°F (871°C) Fired Strength	400 psi
Binder Density	1.11 g/ml
Volume of Mix	18.7 cubic inches per 1 lb. of powder (or 675 cubic centimeters per 1 kg of powder)

\*Kwik-Core powder must be mixed with Kwik-Core binder to be effective. Recommended binder to powder ratio is 32-35 parts binder to 100 parts powder by weight. In general, the higher the ratio of binder to powder, the better the material's fluidity and the longer the working time, but the weaker the core.

## Wax Pattern Preparation

1. Wash, rinse, and dry individual wax patterns to be packed. R&R® Wash-N-Etch pattern cleaner is recommended.
2. If the core in the wax pattern has multiple openings, seal all but one with masking tape.

## Core Mix Preparation & Application

1. Weigh or measure the required amounts of powder and binder separately.  
**Note:** you will have approximately 10 minutes of working time before the mix loses its fluidity. Ensure the total amount of the mix can be used within the working time. Multiple patterns can be filled with one mix.
2. Add the preweighed powder into a mixing container that contains the premeasured binder.
3. Wet out the powder by hand with a mixing paddle, wire whip or whisk. This should take no more than 45 seconds.
4. Mechanically mix the investment at a moderate speed for about 1½ minutes. If the total amount of the mix is manageable, the entire mixing can be done by hand.
5. Place the mixing container on a vacuum table and apply full vacuum until the investment rises in the bowl and collapses. Alternatively, the container can be placed on the top of a vibratory table and vibrated to get rid of air bubbles.
6. Pour the mix down the side of the core so that no air bubbles will be trapped within. To make pouring easier, use a rubber or paper pouring cup. The material may also be piped in with a syringe, pipette or pastry bag.
7. Vibrate the filled pattern to let possible entrapped air bubbles escape.
8. If core pins are necessary (depending on core configuration), insert pieces of ceramic rods into the mix at about the 20 minute mark (counting from step 1).



## RANSOM & RANDOLPH

3535 Briarfield Boulevard | Maumee, OH 43537 USA  
800.800.7496 | 419.865.9497 | 419.865.9997 (FAX)  
www.ransom-randolph.com



Made in the USA

Ransom & Randolph GmbH  
Leipziger Straße 40 | 04571 Rötha Germany  
+49 342 06373999

Investing with Innovation™

---

# KWIK-CORE™ MATERIAL

---

9. Leave the patterns undisturbed for at least 2 hours.
10. After 2 hours, peel off the masking tape (if any) and the filled patterns are ready to be assembled.  
**Note:** do not wash the assembled trees, since the patterns have been previously washed.  
**Note:** if dust-like particles are visible at the surface of the core at this point, it should be brushed or blown off prior to shelling. This is a product of the core mix reaction and may be visible depending on core size or core configuration.

## Dewaxing Tips

For autoclave dewaxing it is important to release the pressure in the autoclave slowly to avoid rupturing the core. A minimum of 2 minutes from peak pressure to atmospheric pressure is recommended.

## Burnout Tips

It is important to remember that when a complete-fill core material is used, you must allow extra time during burnout for the core to be completely burned out. Failure to burnout the core completely may lead to outgassing when metal is poured.

## Storage & Handling

Protect from freezing. Kwik-Core binder must be maintained above 35 °F (2 °C) to prevent the material from precipitating irreversibly and making the product unsuitable for use. Keep in a cool, dry, well-ventilated area. Keep containers tightly closed. Binder stored in transparent or translucent containers should be sheltered from direct sunlight. Shelf life is 1 year from date (MMDDYY) in batch lot number on label. Rotate stock to maximize shelf life.

## Safety

Before handling this material, review the corresponding Safety Data Sheet (SDS).

*As the conditions or methods of use are beyond our control, we do not assume any responsibility and expressly disclaim any liability for any use of this product. Information contained herein is believed to be true and accurate but all statements or suggestions are made without warranty, expressed or implied, regarding accuracy of the information, the hazards connected with the use of the material or the results to be obtained from the use thereof. Compliance with all applicable federal, state, and local regulations remains the responsibility of the user. All potential liability related to the sale and use of this product is limited to the cost of the particular goods sold in their respective transactions.*



---

## RANSOM & RANDOLPH

3535 Briarfield Boulevard | Maumee, OH 43537 USA  
800.800.7496 | 419.865.9497 | 419.865.9997 (FAX)  
www.ransom-randolph.com



Made in the USA

Issue Date: March 21, 2024

Ransom & Randolph GmbH  
Leipziger Straße 40 | 04571 Rötha Germany  
+49 342 06373999

Investing with Innovation™